

LANDING GEAR MOTOR AND RELAY

REF DES / WIRE NUMBER	PART NUMBER	DESCRIPTION	INSTALL ZONE	EFF
-		LANDING GEAR MOTOR AND RELAY		FE
A16		PRINTED CIRCUIT BOARD ASSY-FLAP RELAY (SEE CHAPTER 91-02 FOR A COMPLETE LIST OF COMPONENTS)	231	FE
A19		PRINTED CIRCUIT BOARD ASSY-ANNUN LT (SEE CHAPTER 91-01 FOR A COMPLETE LIST OF COMPONENTS)	232	FE
A19CR42	132408-22	DIODE	232	FE
A19K4	50-384112-1	RELAY	232	FE
B21	58-380090-1	MOTOR-LDG GR	150	FE
CB18	7277-2-5	CIRCUIT BREAKER-LDG GR RELAY	251	FE
CB19	MS24510-30	CIRCUIT BREAKER-LDG GR MOTOR (SUPERSEDED BY 7271-8-30)	251	FE
	7271-8-30	CIRCUIT BREAKER-LDG GR MOTOR (SUPERSEDES MS24510-30)	251	FE
CR22	1.5KE51CA	TRANZORB	150	FE
CR23	1.5KE51CA	TRANZORB	150	FE
GS1	131270-3	GROUND STUD-MAIN SPAR CARRY-THRU	270	FE
J115A	206705-2	CONNECTOR, RECEPTACLE-L LDG GR	730	FE
J115B	66103-2	PIN CONTACT	730	FE
J115C	206966-1	STRAIN RELIEF	730	FE
J56A	207018-1	CONNECTOR, RECEPTACLE-LDG GR LIMIT SW	150	FE
J56B	66103-2	PIN CONTACT	150	FE
J82A	206153-1	CONNECTOR, RECEPTACLE-R LDG GR SAFETY SW	740	FE
J82B	66103-2	PIN CONTACT	740	FE
K17	6046H39B	RELAY-DYNAMIC BRAKE LDG GR	150	FE
P115A	206708-1	CONNECTOR, PLUG-L LDG GR	730	FE
P115B	66105-2	SOCKET CONTACT	730	FE
P115C	206966-1	STRAIN RELIEF	730	FE
P56A	207017-1	CONNECTOR, PLUG-LDG GR LIMIT SW	150	FE
P56B	66105-2	SOCKET CONTACT	150	FE

P82A	206060-1	CONNECTOR, PLUG-R LDG GR	740	FE
P82B	66105-2	SOCKET CONTACT	740	FE
P82C	206062-1	CABLE CLAMP	740	FE
S36	BZ-3AT	SWITCH-R LDG GR SAFETY	740	FE
S38	36-380050-1	SWITCH-LDG GR	150	FE
S39	MS25008-1	SWITCH-LDG GR UP LIMIT	150	FE
S40	MS25026-1	SWITCH-LDG GR DWN POSN LT	740	FE
S45	MS25026-1	SWITCH-LDG GR DWN LIMIT	150	FE
S73	MS25008-1	SWITCH-L LDG GR SAFETY	740	FE
S78	V3-101	SWITCH-LDG GR THROTTLE	231	FE
W20	101-364084-239	BUS BAR	251	FE

CODES OF EFFECTIVITY

FE	E2458,E2468-E3280, EA488-EA646
----	-----------------------------------

Figure 02 : Sheet 1 : LANDING GEAR MOTOR AND RELAY

