



FIG. & ITEM NO.	PART NO.	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
		1 2 3 4 5 6 7		
6	35-590001	TOOLS & EQUIPMENT, LOOSE	NP	1
	35-590101	TOOLS & ACCESSORIES, LOOSE	NP	2
	35-590110	TOOLS & ACCESSORIES, LOOSE	NP	32
	35-590113	TOOLS & ACCESSORIES, LOOSE	NP	33
	35-590116	TOOLS & ACCESSORIES, LOOSE	NP	34
- 1	35-590306	. ADAPTER ASSY, MAIN WHEEL JACK	1	
	35-524190	. LOCK ASSY, CONTROL COLUMN	1	3
	35-524638	. LOCK ASSY, CONTROL COLUMN	1	4
- 2	35-590081-1	. PIN ASSY, CONTROL COLUMN LOCK	1	5
	35-590103	. PIN ASSY, CONTROL COLUMN LOCK	1	20
- 3	35-590077-1	. SHUTTER ASSY, OIL RADIATOR	1	6
	35-590077-11	. SHUTTER ASSY, OIL RADIATOR	1	29
	35-910277-1	. BAFFLE INSTL, NOSE COWL WINTER	NP	21
	35-910277-3	. BAFFLE INSTL, NOSE COWL WINTER	NP	22
	35-910279	. PLACARD, INSTRUCTIONS /ON BAFFLE/	1	
	35-910296	. PLACARD, INSTRUCTIONS /INSIDE CABIN/	1	7
	35-910296-1	. PLACARD, INSTRUCTIONS /INSIDE CABIN/	1	8
	35-910278	. BAFFLE, WINTER LH.	1	
	35-910278-1	. BAFFLE, WINTER RH.	1	21
	35-910278-3	. BAFFLE, WINTER RH.	1	22
- 4	113658-034-00	. STRAP ASSY, STOWAGE BOX	1	28
	R903	. FLIGHT BAG /SUPERSEDES A903/	1	27
- 5	130066-3	. KEY, LOCK /SUPERSEDES 35-590070-1/	2	1
	35-590099-1	. KEY, LOCK	2	2
- 6	35-590060	. COVER ASSY, PITOT TUBE /USE WITH UNHEATED TUBE/	1	
	45-590059	. BOOT ASSY, PITOT TUBE /USE WITH HEATED TUBE/	1	
- 7	50-590106	. WRENCH, SUMP DRAIN	1	
- 8	35-590058	. HANGER ASSY, CLOTHING	1	
	35-590113-13	. CHART, 35TC HORSEPOWER SETTING	1	19
	35-590090	. CALCULATOR ASSY, IO-470C ENGINE	1	9
		/SUPERSEDES 35-590082-13/		
	35-590097	. CALCULATOR ASSY, IO-470N ENGINE	1	10
	35-590115	. CALCULATOR ASSY, DAY READING /IO-520 ENGINE/	1	26
	EF5-1	. BOOK, ENGINE LOG	1	
	AF5-1	. BOOK, AIRPLANE LOG	1	
	35-590074-1	. TROUGH ASSY, OIL DRAIN	1	11
	BE180	. DUCT, ENGINE OIL DRAIN	1	
- 9	300-911-930	. KIT, TUBELESS TIRE INFLATION VALVE	1	12
		/SUPERSEDES 206-108172/		
	98-36533	. INSTRUCTIONS, V35 CRATING & UNCRATING	1	19
	NO NUMBER	. CASE, LEATHER KEY	1	
	35-590113-3	. MANUAL, V35TC FAA APPROVED FLIGHT	1	33
	35-590116-3	. MANUAL, V35ATC FAA APPROVED FLIGHT	1	34
	35-590110-11	. HANDBOOK, S35 PILOTS OPERATING	1	32
	35-590118-31	. HANDBOOK, V35, V35A PILOTS OPERATING	1	19
	35-590113-11	. MANUAL, V35TC OWNERS	1	33
	35-590116-7	. MANUAL, V35ATC OWNERS	1	34
	35-590113-15	. LIST, V35TC PILOTS CHECK	1	33
	35-590116-9	. LIST, V35ATC PILOTS CHECK	1	34
	IDC-2	. MANUAL, OPERATIONS /CONTINENTAL/	1	2
		/SUPERSEDES CS-081/		
	IO-52-2	. MANUAL, OPERATIONS /CONTINENTAL/	1	26
	M60-5A	. BULLETIN, CONTINENTAL MOTOR SERVICE	1	2
	113667	. DIRECTORY, BEECHCRAFT SERVICE FACILITY	1	
	98-32176	. CARD, OWNER NOTIFICATION	1	
	35-590108	. CALCULATOR ASSY, HORSEPOWER, DAY READING	1	26
		/WITH TEFLON BEARING/		
	35-590097	. CALCULATOR ASSY, HORSEPOWER	1	2
		/SUPERSEDES 35-590100/		
	35-590109	. CALCULATOR ASSY, HORSEPOWER, NIGHT READING	1	26

FIG. & ITEM NO.	PART NO.	DESCRIPTION							UNITS PER ASSY	USABLE ON CODE
		1	2	3	4	5	6	7		
6	35-590015	TOOLS & ACCESSORIES, LOOSE /OPTIONAL/	1	1
	35-590102	TOOLS & ACCESSORIES, LOOSE /OPTIONAL/	1	20
- 10	35-590009	. WRENCH, THROTTLE RETAINING NUT SPANNER	1	
- 11	35-590021	. SUPPORT ASSY, TAIL TIE DOWN	1	
	35-590015-9	. CATALOG, MODEL H35 THRU V35 PARTS	1	
- 12	35-590076	. SHAFT ASSY, DIFFERENTIAL NEUTRALIZER	1	25
- 12A	35-590052	. ADAPTER	1	25
- 12B	35-590087-1	. JIG ASSY, DIFFERENTIAL NEUTRALIZER	1	18
- 13	TS1222-4	. WRENCH, FWD UPR, AFT UPR & LWR WING BOLT	1	30
- 14	TS1222-3	. WRENCH, FWD LWR WING BOLT	1	31
	TS1222-4	. WRENCH, FWD LWR WING BOLT	1	26
- 15	TS1171-1	. ADAPTER, WING NUT TORQUE WRENCH	1	30
		/FWD UPPER, AFT UPPER, AFT LOWER/		
- 16	TS1171-2	. ADAPTER, WING NUT TORQUE WRENCH/FWD LWR/	1	30
	35-590024	. COVER ASSY, ENGINE	1	
	35-590027	. COVER ASSY, PROPELLER	2	
	35-590096	. MANUAL, 35 SHOP	1	
	98-32227	. INSPECTION GUIDE, MODEL 35	1	
	35-590063	. BOX ASSY, LANDING GEAR CIRCUIT TESTER	1	
	35-590064	. SLING INSTL, HOISTING	NP	
- 17	35-590064-1	. SLING ASSY, HOISTING	1	
	35-590050-1	. COVER ASSY, ENGINE	1	
	CODE 932-5	. JACK /35-000001/	1	
	35-590053	PANE INSTL, BLIND FLYING /OPTIONAL/	NP	
- 18	35-590002	HANDLE ASSY, TOW	1	
	35-590073-15	HANDBOOK, H35 PILOTS OPERATING	1	13
	35-590079-5	HANDBOOK, J35 PILOTS OPERATING	1	14
	35-590086-3	HANDBOOK, K35, M35 PILOTS OPERATING	1	23
	35-590094-7	HANDBOOK, N35, P35 PILOTS OPERATING	1	15
	115090-19-1	HANDBOOK, MODEL 278 PROPELLER	1	
	15-186	MANUAL, BENDIX PS. SERIES CARBURETOR	1	13
	649742	HANDBOOK, SPERRY DIRECTIONAL GYRO INDICATOR	1	13
	656768	HANDBOOK, SPERRY GYRO HORIZON INDICATOR	1	13
	35-921240	CAP INSTL, FUEL FILLER LOCK /OPTIONAL/	NP	24
	416-85	. CAP ASSY, AUXILIARY FUEL /LOCKING TYPE/	2	24
		/SUPERSEDES 416-25L10 & 416-25L20/		
- 19	416-54	. AXLE, FUEL CAP /SUPERSEDES 416-6/	1	24
- 20	MS20365-428	. NUT /SUPERSEDES AN365-428/	1	24
- 21	416-10	. DISC, FUEL CAP	1	24
- 22	416-15	. WASHER, FUEL CAP	1	24



FIG. & ITEM NO.	PART NO.	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
		1 2 3 4 5 6 7		
6 - 23	416-4	. . PAWL, FUEL CAP /ATTACHING PARTS/	2	24
- 24	416-22	. . SCREW, FUEL CAP.	2	
- 25	AN392-9	. . PIN	2	
- 26	AN960-416L	. . WASHER	4	
- 27	C12046-017-3	. . WASHER, SPRING	4	
- 28	A1059-014-3	. . WASHER, SPRING	4	
- 29	MS29513-10	. . RING, FUEL CAP O /SUPERSEDES AF934-5/	1	24
- 30	416-7	. . BASE, FUEL CAP	1	24
- 31	MS29513-232	. . RING, FUEL CAP O /SUPERSEDES AF934-147/	1	24
- 32	416-5	. . HANDLE, FUEL CAP /ATTACHING PARTS/	1	24
- 33	416-9-1	. . PIN, FUEL CAP/SUPERSEDES 416-9/	1	
- 34	416-350	. . BOLT, EYE /ATTACHING PARTS/	1	24
- 35	MS20365-1032	. . NUT /SUPERSEDES AN365-1032C/	1	
- 36	416-360	. . GASKET, EYEBOLT	1	24

CODES OF EFFECTIVITY

1 D-4866 THRU D-6841	2 D-6842 THRU D-7309
3 D-4866 THRU D-5054	4 D-5055 THRU D-5131
5 D-5132 THRU D-6841	6 D-5291 THRU D-7095
7 D-4866 THRU D-6161	8 D-6162 AND AFTER
9 D-5331 THRU D-6561	10 D-6562 AND AFTER
11 D-4866 THRU D-5069	12 D-5986 AND AFTER
EXCEPT D-5037, D-5058, D-5060, D-5061, D-5065 AND D-5066 BUT INCLUDING D-5071 & D-5111	
13 D-4866 THRU D-5330	14 D-5331 THRU D-5725
15 D-6562 THRU D-7309	16 DELETED
17 DELETED	18 D-5726 AND AFTER
19 D-7977 AND AFTER	20 D-6842 AND AFTER
21 D-4866 THRU D-7949	22 D-7950 AND AFTER
23 D-5726 THRU D-6561	24 D-4866 THRU D-6561
25 D-4866 THRU D-5725	26 D-7310 AND AFTER
27 D-4866 THRU D-7017	28 D-7018 AND AFTER
29 D-7096 THRU D-7309	30 D-4866 AND AFTER
31 D-4866 THRU D-7309	32 D-7310 THRU D-7976
33 D-7977 THRU D-8598	34 D-8599 AND AFTER